

How to test your Fire Sprinkler system:

1. If your sprinklers are connected to a central alarm, inform the fire department that you are going to do a test.
2. Find your water flow test control valve. It may be labeled main drain, inspector test or test and drain.
3. Slowly turn the control valve on (bring the valve in line with the pipe).
4. This will start water running. Let the water run for about 60 seconds. If your system has an alarm you will hear it.
5. Slowly turn the control valve off (the valve will make a corner to the pipe).
6. Write down the date you tested your water flow switch.
7. If any of these steps fail or if you need assistance, contact your plumber.